


Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-M1300	1571477L01	DUST COVER	For MOTOTRBO XPR 6300, XPR 6350,XPR 6500,XPR 6550, DGP 4150,DGP 4150+,DGP 6150, DGP 6150+,XIR P8268 etc...
	CSH-M1300	PMDN4097_R	PMDN4097_R Front Housing, Limited Keypad, with Keypad,Knob,Label etc...	For MOTOROLA CP185,CP1300, CP477,CP476 etc..
	CSH-M1660			For MOTOROLA CP1660,CP1600, etc..

Picture	Our Kit No.	Original Model	Specification	Compatible Products
			Chassic	
	CSH-M88	GP88	with knobs & PTT pad & Dust cove & label	For MOTOROLA GP88 etc...
	CSH-M300	15-80562C01	with knobs & PTT pad & Dust cove & label ,HLN3169A 16-Channel Housing Kit with Speaker and Flex	For MOTOROLA GP300 etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-M88C	2780549B01	Chassis,label one piece	For MOTOROLA GP88/300 etc...
		3680146S03	Knob Volume	For MOTOROLA GP88,GP300,GP88s,P040,P080 etc...
		3680147S07	Knob Freq.16 Position	For MOTOROLA GP88,GP300,GP88s,P040,P080 etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
		7580437C01	Keypad PTT	For MOTOROLA GP88/300 etc...
		1380159S01	Bezel PTT	For MOTOROLA GP88/300 etc...
		3880428C02	Dust Cap	For MOTOROLA GP88/300 etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
		3080560D01	Cable,Speaker/Mic	For MOTOROLA GP88/300 etc...
		5013920A01	Microphone Cartridge and Boot(1405874T02)	For MOTOROLA GP88/300 etc...
		5005589U05	Speaker & Pad,Speaker(7580107A02)	For MOTOROLA GP88/300 etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
		3280545C01	Gasket, Chassis	For MOTOROLA GP88/300 etc...
			Volume ON-OFF Switch	For MOTOROLA GP88/300 etc...
		1880619Z02	Switch Rotary Dip 16 Pos.	For MOTOROLA GP88/300 etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
		39-80188R01	Contact,Battery B+/B-; 2 used	For MOTOROLA GP88,GP300 etc...
	CSH-M88s	GP88s	with knobs & PTT pad & Dust cove & label	For MOTOROLA GP88s etc...
	CSH-M308	1585616Z01	with knobs & PTT pad & Dust cove & label	For MOTOROLA PRO3150,GP308,P040,CT150 etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-M308C	2780518Z03	Chassis,label 2 piece	For MOTOROLA GP88s, GP308 etc...
	CSH-M2000	DS1M001110	with knobs(DS1M001130) & PTT pad(DsM61890003 & Dust cove & label	For MOTOROLA GP2000,GP2100 etc...
		GP2000S	with knobs & PTT pad & Dust cove & label	For MOTOROLA GP2000s etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-M2000C	DSMZ192006	label one piece(DSM2192004)	For MOTOROLA GP2000,GP2100 etc...
			Knob	For MOTOROLA GP2000,GP2100 etc...
			LCD	For MOTOROLA GP2000,GP2100 etc...


Picture	Our Kit No.	Original Model	Specification	Compatible Products
			Volume ON-OFF Switch	For MOTOROLA GP2000,GP2100 etc...
			Contact,Battery B+/B-	For MOTOROLA GP2000,GP2100 etc...
	CSH-M328	1580666Z03	with knobs & PTT pad & Dust cove HLN9820A & label	For MOTOROLA GP328,GP340,GP329,PRO5150 etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-M328	GP328	with knobs & PTT pad & Dust cove HLN9820A & label	For MOTOROLA GP328,GP340,GP329,PRO5150 etc...
	CSH-M360	GP360	with knobs & PTT pad & Dust cove HLN9820A & label	For MOTOROLA GP360 etc...
	CSH-M338	1580666Z04	with knobs & PTT pad & Dust cove & key pad & label	For MOTOROLA GP380,GP338,GP339,PTX760, PRO7150 etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
		5104949J07	7580540Z01 Pad, Display; 5104949J07 LCD Module; 7580637Z01 Pad, LCD Back	For MOTOROLA GP338,GP339,PTX760 etc...
	CSH-M328C	2780518Z01	Chassis,label two pieces	For MOTOROLA GP328/338 etx...
		36-80529Z01	Knob Volume	For MOTOROLA GP328,GP338,GP328plus,Gp338plus ,GP3688,GP3188,GP340,GP360, GP380,GP344,GP388,EX500,EX600, EP450,CP140 etx...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
		36-80530Z02	Knob Freq.16 Position	For MOTOROLA GP328,GP338,GP328plus,Gp338plus ,GP3688,GP3188,GP340,GP360, GP380,GP344,GP388,EX500,EX600, EP450,CP140 etx...
			Volume ON-OFF Switch	For MOTOROLA GP328/338 etx...
			Switch Rotary Dip 16 Pos.	For MOTOROLA GP328,GP338,GP328plus,Gp338plus ,GP340,GP360,GP380,GP344,GP388, EX500,EX600 etx...



Picture	Our Kit No.	Original Model	Specification	Compatible Products
			Gasket, Chassis	
	CSH-M9820A	HLN9820A	DUST COVER	For MOTOROLA GP328/338 etx...
			Contact, Battery B+/B-	For MOTOROLA GP328/338 etx...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-M328+	0104031G98	Non Key Housing with knobs(3680530Z02,3680529 Z01) & PTT pad & Dust cove(JMLN4638) & label	For MOTOROLA GP328Plus,EX500,GP344, GP644,PRO5150 Elite etc...
	CSH-M338+	1586088Z01	Front Cover Assembly with knobs & PTT pad & Dust cove & key pad(7586096Z01) & label	For MOTOROLA GP338Plus,EX600,EX600XLS,GP38 8,GP688,PRO7150 Elite etc...
			LCD	

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-M338C	2786154Z01 1502001P31	Chassis,label two pieces	For MOTOROLA GP328Plus,GP338Plus,EX500, EX600,EX600XLS,GL2000,GP344, GP388,GP644,GP688,PRO5150 Elite,PRO7150 Elite etc...
	CSH-M3688	GP3688	with knobs & PTT pad & Dust cove & label	For MOTOROLA GP3688 etc...
	CSH-M3188	GP3188	with knobs & PTT pad & Dust cove & label	For MOTOROLA GP3188,CP040 etc...


Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-M450	1586391Z01	3680530Z02 Knob Frequency, 3680529Z01 Knob Volume & 3886489Z01 PTT Rubber, 4586439Z01 PTT Plastic & 3886441Z01 Dust cove, 5586445Z02 Latch Assembly, 3286432Z01 Seal Control Shaft, label	For MOTOROLA GP450, CP140 etc...
	CSH-M180	CP180	with knobs & PTT pad & Dust cove & label	For MOTOROLA GP450, CP180 etc...
	CSH-M3688C	2786379Z01	Chassis, label two pieces	For MOTOROLA GP3688, EP450, CP150, CP200, CP040, CP140, CP160, CP180, GP3188 etc..


Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-M838	1505637V04	Cover,Front;Full Keypad	For MOTOROLA MTX838,MTX9000,MTS2000 etc..
	CSH-M838	1505627V04	Not Keypad	For MOTOROLA MTX838,MTX9000,MTS2000 etc..
	CSH-M838C	1505892U06	Chassis (Rear Cover)	For MOTOROLA MTX838,MTX9000,MTS2000 etc..

Picture	Our Kit No.	Original Model	Specification	Compatible Products
 On/Off Volume Control Dedicated Monitor Volume Set Control Button Channel Select Buttons Channel Select LED Indicators Monitor Volume Set Function LED Indicator Microphone Jack Programmable Option Button (Repeats/Talk Around or Local/Distance) Option Button LED Indicator High Quality Audio Output Speaker	CSH-M50		Face Front Cover with knob,K	For MOTOROLA SM50
	CSH-GM300	1580516B01	Housing(1580516B01) with Knobs (3680106M03),keypad(7580517B01,\$1.4).	For MOTOROLA GM300 etc...
	CSH-GM300	1580127L01	Cover,Housing	For MOTOROLA GM300 etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-GM300	7580517B01	keypad(7580517B01).	For MOTOROLA GM300 etc...
	CSS-M9457	HLN9457	16pins Plug	For MOTOROLA GM300,GM338,GM3188,GM3688 etc...
		0980255E01	Power Connector	For MOTOROLA GM300,MaxTrac 900,M10,M120,M130 etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-M5189	HLN5189A	Mounting Hardware with Screw	For MOTOROLA GM300,M10,M120,M130 etc...
	CSH-GM3688	GM3688	Housing with Knobs ,keypad and Gaske	For MOTOROLA GM3688 etc...
	CSH-GM3188	1589332U01	Housing with Knobs ,keypad and Gasket	For MOTOROLA GM3188 etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-GM3188	1589224U01	Upper Cover	For MOTOROLA GM3188 etc...
	CSH-GM3188	2789223U01	Chassis 25W	For MOTOROLA GM3188 etc...
		7589330U01	Keypad	For MOTOROLA GM3188 etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
		5005156Z02	Speaker	For MOTOROLA GM3188 etc...
		3689331U02	Knobs with Knob Spring	For MOTOROLA GM3188 etc...
		0189484U01	Power Cable Assembly	For MOTOROLA GM3188 etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-GM338	1586088B01	Housing Front(1586088B01), including:Gasket,Lens,Lightguide,Knob(3686098B02),label(1364279B14),Key pad(7586091B02).	For MOTOROLA GM338 etc...
	CSH-GM338	1586083B01	1586083B01-Cover,Plastic 25W	For MOTOROLA GM338 etc...
	CSH-GM338	GM338	Chassis	For MOTOROLA GM338 etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
		0986165B01	Power Connector	For MOTOROLA GM338 etc...
	CSH-M7324	GLN7324A	Mounting Hardware with Screw	For MOTOROLA GM338,GM398,GM3688,GM3188,GM339,GM3188,MCX760,MTM800,MTM700,PRO5100 etc...
		GM300	Power Supply with Case	Fit MOTOROLA GM300

Picture	Our Kit No.	Original Model	Specification	Compatible Products
		GM3188	Power Supply with Case	Fit MOTOROLA GM3188
		GM3688	Power Supply with Case	Fit MOTOROLA GM3688
		GM338	Power Supply with Case	Fit MOTOROLA GM338

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-GR300	GR300	Repeater case (310mm x 211mm x 318mm)	Fit MOTOROLA GR300
	CSH-GR3188	GR3188	Repeater case (310mm x 211mm x 318mm)	Fit MOTOROLA GR3188
	CSH-GR3688	GR3688	Repeater case (310mm x 211mm x 318mm)	Fit MOTOROLA GR3688

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-CDR500	CDR500	Repeater case (191mm x 445mm x 343mm)	Fit MOTOROLA CDR500
	CSH-CDR700	CDR700	Repeater case (310mm x 211mm x 318mm)	Fit MOTOROLA CDR700
	CSH-K3107	TK2107/3107	with knobs & PTT pad & Dust cove & label	Fit KENWOOD TK-2107,TK3107,TK2102,TK3102 etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-K3107C	TK2107/3107	Chassis,label two pieces	Fit KENWOOD TK-2107,TK3107,TK2102,TK3102 etc...
	CSH-K2207	TK2207/3207	with knobs & PTT pad & Dust cove & label	Fit KENWOOD TK- 2207,TK3207,TK2202,TK3202,TK2206,TK3206 etc...
	CSH-K2207C	TK2207/3207	Chassis,label	Fit KENWOOD TK-2207/3207

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-K278	TK278/378	knobs for volumen and channel, label, glass, PTT 、 plastic cover, rubber button of 20 each one piece	Fit KENWOOD TK-278/378
	CSH-K278C	TK278/378	Chassis,label	Fit KENWOOD TK-278/378
	CSH-K278G	TK278G/378G	16CH Front Cover with knobs & PTT pad & Dust cove & key pad & label	Fit KENWOOD TK-278G/378G

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-K278G	A02-2397	128CH Front Cover with knobs & PTT pad & Dust cove & key pad & label	Fit KENWOOD TK-278G/378G
	CSH-K278GC	TK278G/378G	Chassis,label	Fit KENWOOD TK-278G/378G
	CSH-K208	TK208/308	with knobs & PTT pad & Dust cove & key pad & label	Fit KENWOOD TK-208/308

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-K22AT	TK22AT/42AT	with knobs & PTT pad & Dust cove & key pad & label	Fit KENWOOD TH-22AT/42AT
	CSH-K3118	TK2118/3118	with knobs & PTT pad & Dust cove & key pad & label	Fit KENWOOD TK-2118/3118
	CSH-K768G	TK768G/868G	Housing with keypad \$2.7,8CH	Fit KENWOOD TK-768G,TK868G etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-K768G	TK768G/868G	Housing with keypad \$2.7,128CH	Fit KENWOOD TK-768G,TK868G etc...
	CSH-K768G	TK768G/868G	Cover,Housing	Fit KENWOOD TK-768G,TK868G etc...
	CSH-K768G	TK768G/868G	Chassis(\$2+\$5.5)	Fit KENWOOD TK-768G,TK868G etc...

Picture	Our Kit No.	Original Model	Specification	Compatible Products
	CSH-K768G	TK768G/868G	Power Cable Assembly	Fit KENWOOD TK-768G,TK868G etc...
	CSH-K768G	TK768G/868G	Antenna Connector Cable	Fit KENWOOD TK-768G,TK868G etc...
		IC-V8	Front Cover Assembly with knobs & PTT pad & Dust cove & key pad & label	Fit ICOM IC-V8

Picture	Our Kit No.	Original Model	Specification	Compatible Products
		IC-V8	Chassis	Fit ICOM IC-V8
		IC-V82	Front Cover Assembly with knobs & PTT pad & Dust cove & key pad & label	Fit ICOM IC-V82
		IC-V82	Chassis	Fit ICOM IC-V82



Manasrekha

Enterprises

Picture	Our Kit No.	Original Model	Specification	Compatible Products
		IC-V85	Front Cover Assembly with knobs & PTT pad & Dust cove & key pad & label	Fit ICOM IC-V85
		IC-V85	Chassis	Fit ICOM IC-V85